PRTFOX
Handheld Inkjet Printer

Contents

Product Introduction

Product Features

Instructions for use

Application scenario

01 Product Introduction

1 Product structure

Print button
Power button: long press for 3 seconds

Upper cover

WIFI indicator

Reset hole:
Forced shutdown by fine needle insertion

Status Indicator

Nozzle protection cover

BENTSAI

Cover button

type-c Power interface
: The indicator light is red when it is turned off and charged, and it goes out when it is fully charged.

2 Packing list

PRTFOX Printer

Ink cartridge

Manual

USB data line

3 Product parameter

Content	Parameter
Model	PRTFOX
Communication mode	WiFi
APP	Android、Ios
Status Display	Green means ready status; blue means printing status; red means alarm status
Languages	Chinese, English, German, Arabic, Spanish, Russian, Japanese, Korean, Italian, Portuguese, French, Hindi, Thai, Vietnamese, Persian, Turkish, Traditional Chinese
Printing Content	Text, numbers, symbols, QR codes, barcodes, pictures, time, date, counter, etc.
Printing height	12.7mm
Printing distance	2-5mm (Distance between nozzle and object)
Ink capacity	42ml
Ink type	Solvent ink cartridge
Ink color	Black, Magenta, Cyan, Green
Printing material	Wood, carton, stone, pipe, metal, plastic, aluminum foil, cable, etc.

Content	Parameter
Image Format	JPG、BMP、PNG
Printing accuracy	300DPI
Printing speed	30m/min
Print area	12.7mm×500mm
Battery capacity	500mAH
Power	5V 1A
Continuous printing time	3 hours
Standby time	3.5 hours
Power interface	type-c
Weight	521g
Size	220*130*45mm
Working temperature	5-35℃
Working humidity	10%-80%

02 Product Features

1 Features

Simple and stylish
Humanized industrial
User friendly compact design

Machine with ink cartridges
Less than the weight of a bottle of milk

Pocket size design
Easy to carry
Anytime, anywhere,

Printing speed can be up to 30m/min
Print as you want and print as you like

2 Portable protective cover

1. Concise and integrated design, the protective cover is multifunctional;
2. The design of the magnetic adsorption to protect the nozzle, easy operation with protection;
3. Prevent dry head and provide physical protection to make the ink cartridge more durable;
4. Just put on the protective cover of the nozzle after use, no need to remove ink cartridges frequently;

3 Push-in installation

1. The direct-push ink cartridge installation design allows you to install it with one push. It also provides upgrade protection for the ink cartridges;
2. The ink cartridges can be disassembled and assembled with electricity, there is no need to worry about damaging the print head;
3. Inductive integrated cover design, closing the cover can trigger the sensor. The device will enter into the printing state immediately.

Removable print head module design.
Can print in a small space with a height
less than 1.3cm and a width Larger than
3.6cm.

Gouki Gouki

Gouki Gouki

Gouki

Gouki

Гоикі Gouki

1、Chinese Fonts：宋体、华文彩云、华文行楷、微软雅黑、华文琥珀

2、Foreign fonts：Arial/Arial Black、Helvetica、Garamond、Frutiger、Bodoni、Futura、Times、Akzidenz Grotesk、Offician、Gill Sans

6 Language settings

Chinese, English, German, Arabic, Spanish, Russian, Japanese, Korean, Italian, Portuguese, French, Hindi, Thai, Vietnamese, Persian, Turkish, Traditional Chinese

1.Operation interface

2.APP Download Entry

Andriod
English Version

IOS

Andriod
Chinese Version

03 Instructions for use

1 Printing steps

1.Press the power button for 3 seconds, the indicator light turns on (the indicator light changes from white to green, and the printer is ready).

The indicator light from white to green

Power button

2. Connect the mobile phone to the WIFI with the machine name "PRTFOX--xxxxx" and enter the password: 12345678. After the connection is successful, the WIFI status light will change from blue to green.

12:00

〈设置   Wi-Fi

HP-Print-32-ENVY 5530 series   🔒 🛜 ⓘ

M.2   🔒 🛜 ⓘ

megain2.4G   🔒 🛜 ⓘ

megain5G   🔒 🛜 ⓘ

MERCURY_53D0   🔒 🛜 ⓘ

OrayBox-A294   🛜 ⓘ

PRTFOX-070037   🔒 🛜 ⓘ

TP-LINK_4507   🛜 ⓘ

When the status light changes from blue to green, the connection is successful

Connect and enter password

BENTSAI

3. "add"and "edit" the text you need, click "Print", the interface displays "Printing X times".

2、
Click to
print

1、
Click
to edit
text

Transmission
success
interface display

4. After the machine's indicateor light turns to blue, it means it enters the printing state, press the print button and print the content you need.

indicateor
light turns
to bule

04 Application scenario

1 Usage Scenarios

DIY Items

Home application

Outdoor Entertainment

Office Using

Production and retail

Thanks!